



COOKTOP PARTS

For Models: RS675PXGB10, RS675PXGQ10, RS675PXGT10
(Black) (White) (Biscuit)


30" DROP-IN
ELECTRIC OVEN
SELF CLEAN

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

COOKTOP PARTS


1	Literature Parts
LIT8300649	Installation Instructions
LIT8300666	Use & Care Guide
LIT8301348	Tech Sheet
LIT3191638	Safe Cooking Tips
2	3192459 Burner Box
3	3192330 Bracket, Mounting
	3177991 Screw
4	Cooktop
	8284709 Biscuit
	3191168 White
	3191167 Black
5	3192575 Clip, Mtg. (4)
	3400843 Screw
6	Panel, Control
	8284707 Biscuit
	3191229 White
	3191228 Black
7	Switch, Infinite
	3191471 Use W/6" Surface (Blue Shaft)
	3191473 Use W/8" Surface (Red Shaft)
	3400855 Screw, 8-32 x 1/4
8	4456181 Light, Indicator
11	Pan, Surface
	3195208 6" Pan
	3195209 8" Pan
12	Element, Surface
	8053266 6" Burner
	8053268 8" Burner
14	Knob, Control
	3196232 White
	8272506 Biscuit
	3196231 Black
15	3183956 Seal, Switch Shaft (4)
18	Trim, Extension
	3192103 White
	8300518 Biscuit
	3192102 Black
19	3195917 Clip, Element



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RS675PXGB10, RS675PXGQ10, RS675PXGT10
(Black) (White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	4456311	Control Panel Assy. White
	4456309	Biscuit
	4456312	Black
		W/Membrane Switch
	3400832	Screw
2	4451034	Gasket, Control Panel
3	8301345	Microcomputer
	4449745	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RS675PXGB10, RS675PXGQ10, RS675PXGT10
(Black) (White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: RS675PXGB10, RS675PXGQ10, RS675PXGT10
(Black) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			11	4452368	Oven Light Assy	37	4451442	Thermostat (TOD) (Temp.) SPST
1		Trim, Side (Right Hand)	12	4452166	Bulb, Light	43	4455530	Base, Chassis
	4450845	White	14	4455612	Frame, Front	49	4448933	Retainer, Gasket
	4452120	Biscuit		4449040	Screw		4449154	Screw
	4450844	Black		4450118	Nut	50	4451747	Cover, Back
		(Left Hand)	15	4455382	Gasket, Door		4449809	Screw
	4450848	White	19	4451478	Support, Insulation	53	4449845	Support, Bracket
	4452121	Biscuit		4449809	Screw		4449809	Screw
	4450847	Black	21		Rail, Side		4449809	Screw
	8281236	Screw		4450579	Right Side	55		Trim, Bottom
				4450580	Left Side		4448478	White
3		Hinge Receiver		4448444	Grommet		4452415	Biscuit
	4455605	Left Hand	22	8301268	Latch, Motorized		4448477	Black
	4455606	Right Hand		4449154	Screw	FOLLOWING PARTS NOT ILLUSTRATED		
4	4448520	Bumper, Door	25	4455641	Side, Chassis (R.H. & L.H.)	INSULATION		
5	4452260	Spacer, Foam		4449809	Screw		4449316	Insulation, Wrap
7	4455865	Top Chassis	26	4452234	Back, Chassis		4450365	Insulation, Back
	4449809	Screw		4449809	Screw			
9	4452158	Tube, Vent	27		Liner, Oven (Not serviceable)			
	3196176	Screw	29	4455636	Sensor			
10	4452165	Lens, Light		4449154	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: RS675PXGB10, RS675PXGQ10, RS675PXGT10
(Black) (White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4455618	Door Liner
2		Hinge, Door
	8300571	R.Side
	8300572	L.Side
	4449743	Screw
3	4449259	Glass, Inner
4	4451722	Insulation, Door

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

7	4449263	Glass, Inner (2)
9	4451668	Retainer, Glass
	4449809	Screw
13		Door Handle
	4448855	White
	4452860	Biscuit
	4448854	Black
14	4450813	Bracket, Handle
	4451040	Screw
15		Door Assembly, Glass
	8300899	White
	8300894	Biscuit
	8300903	Black


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

19	4450362	Shield, Heat
	4449809	Screw
20	8300778	Retainer, Glass
	4449809	Screw
21	8300820	Seal, Door Top
23		Retainer, Clip
	4450864	White
	4452119	Biscuit
	4450863	Black
24	4455257	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RS675PXGB10, RS675PXGQ10, RS675PXGT10
(Black) (White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
2	4456103	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RS675PXGB10, RS675PXGQ10, RS675PXGT10
(Black) (White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw, 8-18 x 3/8
2	4455178	Elbow, Vent Top

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

3	4455334	Blower
	4455352	Bracket
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	4451761	Plate, Service
10	4451985	Suppressor
11	4449868	Block, Terminal
	3400080	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

14		Side, Control Compt.
	3191832	Right
	3191833	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
20	3191842	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RS675PXGB10, RS675PXGQ10, RS675PXGT10
(Black) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

3191220	Harness, Wire (Main)
8301080	Harness, Wire
FE02313	Bushing (EDC)
4451163	Conduit
4448664	Clamp
4449809	Screw
112432	Nut
4450800	Screw, Ground
3192236	Harness, Wire (Infinite Switch)
4455592	Harness, Wire (Light)
4452222	Spacer, Harness
4454384	Ground, Wire
3400015	Screw, Ground

Miscellaneous

814381	Hinge Pin Kit
4448950	Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST